



Components






1. **Power/Menu Button** – Turn on/off the Jetpack. Shows the Jetpack menu and information



Operation Status

	Operations	Actions
	Turn On	Press and hold the Power button for 2 seconds.
	Turn Off	Press and hold the Power button until “Goodbye” message appears.
	Display Wake-Up	When the display is off (sleep mode), the first quick press of the Power button wakes up the display.
	Info Display	When the display is on each time the Power button is pressed quickly, the WiFi Name and Password display.

Charging Indicator Light

	Colors	Charging Status
	Off	The Jetpack is not connected to a charger.
	Red	The Jetpack is connected to a charger and is currently charging.
	Green	The Jetpack is connected to a charger and the battery is fully charged.

2. Power Indicator










	Colors	Charging Status
	Off	The Jetpack is off.
	White/Blinking	The Jetpack is on.

3. **Display** – Provides connection and battery status, network signal strength, roaming status, and the number of users connected with Wi-Fi.
4. **Charger Port** – The USB charger connects here.

Device Display




Display Icon




ICON	DESCRIPTION
 Network Signal Strength	Shows network signal strength. 
 Activity Indicator	Appears when data is being transferred between the mobile network and your Jetpack. 
 Connected Devices	Shows the number of connected devices. When the Jetpack can't support any more devices, MAX is shown. 
 Battery Charge Indicator	Shows the battery charge status. 
 Charging	Appears when battery is charging.

Battery Management

Your Jetpack is equipped with a replaceable rechargeable battery. It will work from its charged battery alone, or when the device is plugged into a power source.

Note: Please do not attempt to open or disassemble your Jetpack and the battery pack. Doing so may cause damage that voids your warranty.

Charge the battery by plugging in the charger provided together with your Jetpack. While the battery is charging, the battery charging icon  displays, and the power button illuminates red

. When the battery is charged, the battery icon is solid , the power button illuminates green .

IMPORTANT! Please use only an approved charger to charge your Jetpack. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void the warranty.
